


MANUAL TENSIONING TOOL


1. | Positon the tail through the large center area of the tool.



2. | Rest the blade of the tool against an edge on the load and pull the handle towards you to apply tension to the strap.



3. | Pull the slack out of the strap and repeat steps 1 and 2.



4. | Pull until you reach desired tension.

